

1. Introduction

Thank you for purchasing PLANET CS6-PWR550-AC and CS6-PWR550-DC 550-watt Redundant Power Supply Unit for CS-6306R.

CS6-PWR550-AC	550-watt AC Power Supply for CS-6306R, AC 100-240V~, 7A Max
CS6-PWR550-DC	550-watt DC Power Supply for CS-6306R, DC 36-72V \Rightarrow , 20A Max

- 1 -

3. Installing and Removing the Redundant Power Supply Unit

Before installation, please be sure to read this user's manual carefully to complete machine installation. This manual shows how to quickly install and remove the CS6-PWR550-AC or CS6-PWR550-DC from the CS-6306R.

The CS-6306R is equipped with one 100~240V AC power supply unit that comes with the package, and provides two spare power supply slots for a redundant power supply unit. The CS6-PWR550-AC features a switchable input option of 100V-240V AC.



Note

The CS-6306R supports hot-swapping and power redundancy backup. The 2nd and 3rd AC or DC power modules can directly slide into the chassis while the system is operating.

- 3 -

2. Physical Description

Front panel of CS-6306R




Figure 1. Power slots of CS-6306R

- 2 -




Figure 2. Front panel of CS-6306R

To install the CS6-PWR550-AC or CS6-PWR550-DC into the CS-6306R, slide the CS6-PWR550-AC into the CS-6306R.



Caution

Please slide in the CS6-PWR550-AC module first before plugging in the power cord.

- 4 -

www.PLANET.com.tw

550-watt AC/DC Power Module for CS-6306R

▶ **CS6-PWR550-AC/DC**



PLANET Technology Corp.

10F., No. 96, Minquan Rd., Xindian Dist., New Taipei City 231, Taiwan

Warning:
This is a class A product. In a domestic environment this product may cause radio interference in which case the user may be required to take adequate measures.

2351-A98130-000



To remove a power supply unit from the CS-6306R, press and hold the blue supply lever to the left till it is totally pulled out from the power supply unit.



Note

Please put back the front cover after the CS6-PWR550-AC or CS6-PWR550-DC module is removed.



Caution

Please plug out the power cord before plugging out the CS6-PWR550-AC.




Figure 3. Installing/removing the CS6-PWR550-AC